



1. Remove contents from bag.



2. Extrusions with allen key screw are the bottom legs.



3. Hand tighten thumbscrew to secure leg into base.



4. Repeat Step 3 with second extrusion leg.



5. Align extrusions, thumbscrews from each extrusion should be aligned.



6. Slide thumbscrews to span both extrusions & tighten to secure extrusion legs together.



7. Repeat Step 6 with second extrusion leg.



8. Place monitor bracket on top of both extrusion legs.



9. Slide thumbscrews to span both extrusions & tighten to secure legs together.



10. Repeat Step 9 on the second extrusion to complete the stand set-up.



11. Place provided monitor brackets onto your monitor.



12. Carefully hang your monitor on the monitor bracket



13. Your Portable Monitor Stand is now complete!